

PT1545R / PT1545P Touch Screen Monitor

USER'S GUIDE

www.planar.com

The information contained in this document is subject to change without notice. This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be reproduced, translated to another language or stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission. Windows is a registered trademark of Microsoft, Inc. Other brand or product names are trademarks of their respective holders.

The test results show that this device meets the FCC rules. Those limits are set to protect residential areas from the devices with harmful emission. This device will produce, use and radiate radio frequency energy. In addition, failure to follow the user's manual to install or use this device might produce harmful interference with radio communication. Not withstanding the foregoing, it does not guarantee that this type of harmful interference does not occur in some special installations. The interference caused by this device to the reception of radio or television signals may be verified by turning it on and off. Any changes or modifications to this TFT LCD would void the user's authority to operate this device.

Important Recycle Instructions:

Lamp(s) inside this product contains mercury. This product may contain other electronic waste that can be hazardous if not disposed of properly. Recycle or dispose in accordance with local, state, or federal laws. For more information, contact the Electronic Industries Alliance at <a href="https://www.eiae.com/www.e

For more information on how to recycle your product, please visit <u>WWW.PLANAR.COM/GREEN</u>.

Table of Contents

Usage Notice

About PT1545R/PT1545P 2 Touch Screen for PT1545R 3 Touch Screen for PT1545P 3 Package Overview 4 Installation Product Overview 5 Front View 5 PT1545R Bottom View (Without Stand) 5 PT1545P Bottom View (Without Stand) 5 Start Your Installation 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 14	Precautions	1
Touch Screen for PT1545R 3 Touch Screen for PT1545P 3 Package Overview 4 Installation 4 Product Overview 5 Front View 5 PT1545R Bottom View (Without Stand) 5 PT1545P Bottom View (Without Stand) 5 Start Your Installation 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls 1 Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Pr0duct Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes	Introduction	
Touch Screen for PT1545R 3 Touch Screen for PT1545P 3 Package Overview 4 Installation 4 Product Overview 5 Front View 5 PT1545R Bottom View (Without Stand) 5 PT1545P Bottom View (Without Stand) 5 Start Your Installation. 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls 12 Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Pr0duct Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes <th>About PT1545R/PT1545P</th> <th>2</th>	About PT1545R/PT1545P	2
Touch Screen for PT1545P	Touch Screen for PT1545R	3
Package Overview		
Product Overview 5 Front View 5 PT1545R Bottom View (Without Stand) 5 PT1545P Bottom View (Without Stand) 5 Start Your Installation 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Install Instructions 23 <		
Front View 5 PT1545R Bottom View (Without Stand) 5 PT1545P Bottom View (Without Stand) 5 Start Your Installation 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545R 17 PT1545R 17 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545R Install Instructions 23	Installation	
Front View 5 PT1545R Bottom View (Without Stand) 5 PT1545P Bottom View (Without Stand) 5 Start Your Installation 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545R 17 PT1545R 17 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545R Install Instructions 23	Product Overview	5
PT1545R Bottom View (Without Stand) 5 PT1545P Bottom View (Without Stand) 5 Start Your Installation 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545R 17 PT1545R Optional Calibration Tool Install 20 PT1545R Install Instructions 23 PT1545P Install Instructions 23 PT1545P Install Instructions 25		
PT1545P Bottom View (Without Stand) 5 Start Your Installation 6 Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545P 17 PCOmpatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545P Install Instructions 23 PT1545P Install Instructions 25	PT1545R Bottom View (Without Stand)	5
Connecting the Display (Figure 8.1) 7 (Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 20 PT1545P Install Instructions 23 PT1545P Install Instructions 25		
(Figure 8.1) 8 Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545P Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545P Install Instructions 23 PT1545P Install Instructions 23 PT1545P Install Instructions 25		
Kensington Security Slot 9 VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 20 PT1545P Install Instructions 23 PT1545P Install Instructions 25		
VESA Mount Your Monitor 10 Remove the Deskstand 11 User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 23 PT1545P Install Instructions 25	(Figure 8.1)	8
Remove the Deskstand		
User Controls Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 23		
Side Panel Controls 12 How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25	Remove the Deskstand	11
How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix 15 Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 23 PT1545P Install Instructions 25	User Controls	
How to Use the OSD Menus 13 On-Screen Display Menus 14 Appendix 15 Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 23 PT1545P Install Instructions 25	Side Panel Controls	12
On-Screen Display Menus 14 Appendix 15 Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
Troubleshooting 15 Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
Warning Signal 16 No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25	Appendix	
No Signal 16 Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25	Troubleshooting	15
Going to Sleep 16 Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
Out of Range 16 Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
Product Dimensions 17 PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
PT1545R 17 PT1545P 18 Compatibility Modes 19 Touch Screen Driver Installation 20 PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
PT1545P		
Compatibility Modes19Touch Screen Driver Installation20PT1545R Optional Calibration Tool Install20PT1545P Optional Calibration Tool Install21PT1545R Install Instructions23PT1545P Install Instructions25		
Touch Screen Driver Installation20PT1545R Optional Calibration Tool Install20PT1545P Optional Calibration Tool Install21PT1545R Install Instructions23PT1545P Install Instructions25		
PT1545R Optional Calibration Tool Install 20 PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
PT1545P Optional Calibration Tool Install 21 PT1545R Install Instructions 23 PT1545P Install Instructions 25		
PT1545R Install Instructions		
PT1545P Install Instructions 25		

Usage Notice



Warning - To prevent the risk of fire or shock hazards, do not expose this product to rain or moisture.



Warning - Please do not open or disassemble the product as this may cause electric shock.

Precautions

Follow all warnings, precautions and maintenance as recommended in this user's manual to maximize the life of your unit.

Do:

- · Turn off the product before cleaning.
- Touch screen surface may be cleaned using a soft clean cloth moistened with mild window glass commercial cleaners or 50/50 mixture of water and isopropyl alcohol.
- Use a soft cloth moistened with mild detergent to clean the display housing.
- Disconnect the power plug from AC outlet if the product is not going to be used for an extended period of time.

Don't:

- Do not touch the LCD Display screen surface with sharp or hard objects.
- Do not use abrasive cleaners, waxes or solvents for your cleaning.
- Do not operate the product under the following conditions:
 - Extremely hot, cold or humid environment.
 - Areas susceptible to excessive dust and dirt.
 - Near any appliance generating a strong magnetic field.
 - In direct sunlight.

Introduction

About PT1545R/PT1545P

The PT1545R/PT1545P is a 15" flat panel screen with an active matrix, thin-film transistor (TFT) liquid crystal display (LCD).

This unit is to be used as commercial and light industrial equipment only.

Features include:

- · Direct Analog signal input
- Active matrix TFT LCD technology
- 1024 x 768 XGA resolution
- 15" viewable display area
- 31.5 ~ 60 KHz horizontal scan
- 56 ~ 75 Hz high refresh rate
- 0.297mm x 0.297mm pixel pitch
- · Auto adjustment function
- Multilingual OSD user control
- · Kensington security slot
- 100 mm VESA mount
- · Removable base for flexible mounting solutions.
- PT1545R 5-wire resistive touch screen with dual RS-232 Serial/USB controller
- PT1545P Projected Capactive touch screen with USB controller
- Build-in audio-1W x 2

Touch Screen for PT1545R

· 5-wire resistive touch screen for finger and stylus input

• Surface: Anti-glare treatment

Interface: Dual RS-232 Serial/USB controller

• Transmittance: 82%±5%

• HID: Windows® 7/8

 Driver: Windows® 7/8, VISTA, XP, 2000, ME, 98, NT 4.0, CE, XP Embedded, Linux kernel 2.6.x (32 bit & 64 bit), Apple® Mac OS


Touch Screen for PT1545P

· Projected Capactive touch screen for finger input only

Surface: Glare treatment
Interface: USB controller
Transmittance: 90±5%
HID: Windows® 7/8

 Driver: VISTA, XP, 2000, CE, XP Embedded, Linux kernel 2.6.x (32 bit & 64 bit), Apple[®] Mac OS


Package Overview




Installation

Product Overview


Front View



• PT1545R Bottom View (Without Stand)




• PT1545P Bottom View (Without Stand)





Start Your Installation

Please follow these instructions so that you can hookup the cables to associated connector.

- 1. Lay the display flat on an even surface.
- 2. Move the stand into position as seen in the step 2 diagram.
- 3. Remove the cable cover as seen in the step 3 diagram.
- 4. Connect the cables to the appropriate connectors as seen in the step 4 diagram. Use step 4-1 diagram if using the RS-232 serial connector. Use the step 4-2 diagram if using the USB connector.
- 5. Position all cables under the cover lip as seen in the step 5 diagram.
- 6. Re-attach the cable cover . Remove the screw (CBM M3x6) from the accessory box, and insert the screw into the cable cover and monitor as seen in the step 5 diagram.







Connecting the Display (Figure 8.1)

To setup this display, please refer to the following figure and procedures.

- 1. Be sure all equipment is turned off.
- 2. Connect the AC power cord to the power connector on the monitor and the other end into an electrical outlet (8.1).
- 3. Connect the D-SUB cable from the display's VGA input connector to the D-SUB connector of your host computer and tighten the screws (8.1).
- 4. Connector the audio-in cable from the audio input port of your display to the audio out port of your computer (8.1).
- 5. Connect the RS-232 or USB cable from the RS-232 or USB port of your display to the RS-232 port or USB port (8.1) of your computer.
- 6. Configure the touch screen. Refer to the "Touch Screen Driver Installation" section on page 20.
- 7. Once the touch screen is configured, the monitor is ready for use.


/\ Notice!

To ensure the display works well with your computer, please configure the display mode of your graphics card to make it less than or equal to 1024 x 768 resolution and make sure the timing of the display mode is compatible with the display.


We have listed the compatible "Video Modes" of your display in the appendix (on page 19) for your reference.

(Figure 8.1)

PT1545R




PT1545P



Kensington Security Slot


The monitor can be secured to your desk or any other fixed object with Kensington lock security products. The Kensington lock is not included.



VESA Mount Your Monitor

This monitor conforms to the VESA Flat Panel Mounting Physical Mounting Interface standard which defines a physical mounting interface for flat panel monitors, and corresponding with the standards of flat panel monitor mounting devices, such as wall and table arms. The VESA mounting interface is located on the back of your monitor.

To mount the monitor on an UL-listed swing arm or other mounting fixture, follow the instructions included with the mounting fixture to be used.






Please select the proper screws!

The distance between the back cover surface and the bottom of the screw hole is 11 mm. Please use four M4 screws diameter with proper length to mount your monitor.

Please note: the mounting stand must be able to support at least 11 lbs (5Kg).


Remove the Deskstand



Remove 4 screws and then remove hinge.


User Controls

Side Panel Controls



OSD Key	Menu off status	Menu on status		
E	Menu appear	Menu disappear/ return to main item		
A	Brightness	Main item select up/ Adjust up		
•	Mute	Main item select down/ Adjust down		
4	Enter/Select sub-item function			
மு	Power On/Off			

How to Use the OSD Menus



- 1. Press the "MENU" button to pop up the "on-screen menu" and press "Up" or "Down" button to select among the six functions in the main menu.
- 2. Choose the adjustment items by pressing the "Enter" button.
- 3. Adjust the value of the adjustment items by pressing the "Up" or "Down" button.
- 4. With the OSD menu on screen, press "Menu" button to return main menu or exit OSD.
- 5. The OSD menu will automatically close, if you have left it idle for a pre-set time.
- 6. To Lock the OSD / Power menu buttons, please follow the instructions below. (Please note: the monitor has to be turned ON with a valid signal pre-set)
 - (a.) Press "Menu" key, the OSD menu will pops upon display.
 - (b.) Press and hold the "Menu" key again with the OSD menu on the screen, the OSD menu will disappear. Then press the "Power" key 1 time while the menu key is still being pressed. The "Lock/Unlock" menu will appear for 3 seconds.
 - (c.) Use the "Enter" key to select OSD or Power setting then set at "Lock" by pushing the "UP" or "Down" button.
 - (d.) When the "UP" or "Down" button is released, the previous setting will be saved and exit the "Lock/Unlock" menu automatically.
- 7. To Unlock the OSD / Power menu buttons, please follow the instructions below.

(Please note: the monitor has to be turned ON with a valid signal pre-set)

- (a.) Press and hold the "Menu" key then press the "Power" key simultaneously, the "Lock/Unlock" menu will appear for 3 seconds.
- (b.) Use the "Enter" key to select OSD or Power setting then set at "Unlock" by pushing the "UP" or "Down" button.
- (c.) When the "UP" or "Down" button is released, the previous setting will be saved and exit the "Lock/Unlock" menu automatically.

Please note:

- a. When the OSD Lock function is selected, this indicates that all the buttons except "power" button are now disabled.
- b. When the Power Lock function is selected, this indicates that the power key is disabled; user can not to turn off the monitor by "Power" key.

On-Screen Display Menus

Main OSD Menu:

ITEM	CONTENT		
Contrast	The monitor luminance level control.		
Brightness	The monitor backlight level control.		
Auto Adjust	Fine-tune the image to full screen automatically.		
Left/Right	Moving screen image horizontal position to left or right.		
Up/Down	Moving screen image vertical position to up or down.		
Horizontal size	The screen image horizontal dot clock adjustment.		
Fine	The screen image pixel phase adjustment.		
OSD Left/Right	Moving OSD menu horizontal position to left or right.		
OSD Up/Down	Moving OSD menu vertical position to up or down.		
OSD Time out	OSD auto-disappear time selection.		
OSD Language	OSD menu language selection. (English, French, Japanese, Deutsch, Spanish, Italian, Traditional Chinese and Simplified Chinese)		
Factory Reset	Factory default value restored.		
RGB	Color temperature selection. (9300K, 6500K, 5500K, 7500K, User)		
Volume	Audio volume adjustment.		
Mute	Audio On/Off control.		

Appendix

Troubleshooting

If you are experiencing trouble with the display, refer to the following. If the problem persists, please contact your local dealer or our service center.

Problem: No image appears on screen.

- ► Check that all the I/O and power connectors are correctly and well connected described in the "Installation" section.
- ▶ Make sure the pins of the connectors are not crooked or broken.

Problem: Partial Image or incorrectly displayed image.

- ▶ Check to see if the resolution of your computer is higher than that of the display.
- ▶ Reconfigure the resolution of your computer to make it less than or equal to 1024 x 768.

Problem: Image has vertical flickering line bars.

- ▶ Use "Fine" to make an adjustment.
- ► Check and reconfigure the display mode of the vertical refresh rate of your graphic card to make it compatible with the display.

Problem: Image is unstable and flickering

▶ Use "Horizontal size" to make an adjustment.

Problem: Image is scrolling

- ▶ Check and make sure the VGA signal cable (or adapter) is securely connected.
- ► Check and reconfigure the display mode of the vertical refresh rate of your graphics card to make it compatible with the display.

Problem: Vague image (characters and graphics)

► Use "Fine" to make an adjustment. If this problem still exists, use "Horizontal size" to make an adjustment.

Warning Signal

If you see warning messages on your screen, this means that the display cannot receive a clean signal from the computer graphics card.

Below are the three kinds of Warning Signal. Please check the cable connections or contact your local dealer or Planar for more information.

No Signal

This message means that the display has been powered on but it cannot receive any signal from the computer graphics card. Check all the power switches, power cables, and VGA signal cable.

Going to Sleep

The display is under the power saving mode. In addition, the display will enter power saving mode when experiencing a sudden signal disconnecting problem.

The monitor can be activated by pressing any key on the keyboard, triggering the mouse or touching the screen.


Out of Range

This message means that the signal of the computer graphic card is not compatible with the display. When the signal is not included in the "Video Modes" list we have listed in the Appendices of this manual, the monitor will display this message.


Product Dimensions

PT1545R


► Front View



► Side View




► Top View




PT1545P


► Front View



► Side View



► Top View



Compatibility Modes

Mode	Resolution	H-Frequency (KHz)	V-Frequency (Hz)
IBM VGA	720 x 400	31.47	70
IBM VGA	640 x 480	31.47	60
VESA VGA	640 x 480	37.86	72
VESA VGA	640 x 480	37.50	75
VESA SVGA	800 x 600	35.16	56
VESA SVGA	800 x 600	37.88	60
VESA SVGA	800 x 600	48.08	72
VESA SVGA	800 x 600	46.88	75
VESA XGA	1024 x 768	48.36	60
VESA XGA	1024 x 768	56.48	70
VESA XGA	1024 x 768	60.02	75
Apple Mac II	640 x 480	35.00	66
Apple Mac	832 x 624	49.72	75

Touch Screen Driver Installation

The PT1545R is available with both RS232 and USB connections. The touch driver is located at www.planar.com/support for these operating systems: Windows® 7/8, VISTA, XP, 2000, ME, 98, NT 4.0, CE, XP Embedded, Linux kernel 2.6.x (32 bit & 64 bit), Apple® Mac OS.

The PT1545P is available with USB connection. The touch driver is available at www.planar. com/support for these operating systems: Windows® 7/8, VISTA, XP, 2000, CE, XP Embedded, Linux kernel 2.6.x (32 bit & 64 bit), Apple® Mac OS. (Windows 7/8 Multi touch without driver)

Please Note:

- 1. The PT1545R/PT1545P is Microsoft® Windows® HID (Human Interface Device) compatible if you use the USB touch screen interface. No additional software driver is required for general operation of the touch screen. A calibration tool can be installed for improved touch position accuracy. See "Optional Calibration Tool Install" section for more information.
- 2. For PT1545P, the system requires 15 seconds for Windows 7/8 to process the touch program while turning power on/off or plugging/unplugging USB cable.

PT1545R Optional Calibration Tool Install:

If you would like to use the Optional Calibration Tool, follow the instructions below. Please note: the calibration tool supports Windows® 7/8, VISTA, XP, XP Embedded, 2000, 98 and ME operating systems via USB only.


- 1. Visit www.planar.com/support
- 2. Select the model name, part number and operating system.
- 3. Click on "Calibration Utility".
- 4. The HID calibration tool will automatically open. From here the user can choose to do the following:
 - a. 4 Points Calibration
 - b. 9 Points Linearization
 - c. 25 Points Linearization
 - d. Clear
 - e. Draw Test
 - f. Advanced. In the Advanced settings area the user may do the following:
 - i. Adjust the Double Click Area.
 - ii. Enable auto right click and adjust the auto right click time.
 - iii. Choose to be either in the HID Mouse Mode or HID Digitizer Mode (Windows® 7/8, Vista).
 - i v. Simply click the "Apply" button once the settings are finalized.


PT1545P Optional Calibration Tool Install:

Calibrating the touch screen in Windows 7/8:

- 1. Tap the Start button, Control Panel and then Hardware and Sound.
- 2. Under Tablet PC Settings, tap Calibrate the screen for pen or touch input.
- 3. On the Display tab, under Display options, tap Calibrate and then Yes to allow the program to make changes.
- 4. Follow the on-screen instructions to calibrate the touch screen.









PT1545R Install Instructions:

If you are using a PC running Windows® 7/8, VISTA, XP, 2000, ME, 98, NT4.0, follow the instructions below:

- 1. Power on the PC.
- 2. Be sure the USB or the RS-232 Serial cable is connected from the PC to the display.
- 3. Visit www.planar.com/support.
- 4. Follow the step-by-step instructions as shown on the pop-up windows.

If you are using a PC running driver Linux kernel 2.6.x (32 bit & 64 bit), follow the instructions below:

- 1. Power on the PC.
- 2. Be sure the USB cable is connected from the PC to the display.
- 3. Visit www.planar.com/support.
- 4. Follow the step-by-step instructions as shown on the pop-up windows.

If you are using a PC running Windows® XP Embedded, follow the instructions below:

Express:

- 1. Power on the computer.
- 2. Make sure that the RS232 or USB cable is connected to the computer.
- 3. Be sure that your EWF is disabled. If your EWF is enabled, please disable the EWF by using the EWF Manager command.
- 4. Once the EWF is disabled click on the XP driver at www.planar.com/support. and follow the step-by-step instructions as shown on the pop-up windows.

Custom:

- 1. Power on the computer.
- 2. Make sure that the RS232 or USB cable is connected to the computer.
- 3. Follow the step-by-step instructions found in the zipped file at www.planar.com/support.

If you are using a PC running Windows® CE, follow the instructions below:

- 1. Power on the computer.
- 2. Make sure that the RS232 or USB cable is connected to the computer.
- 3. Using Platform Builder, build an image file by following the step-by-step instructions found in the zipped file at www.planar.com/support.

If you are using a PC running Linux or Apple[®] Mac OS, follow the instructions below:

- 1. Power on the computer.
- 2. Make sure that the RS232 or USB cable is connected to the computer.
- 3. Follow the step-by-step instructions found in the zipped file at www.planar.com/support.

When changing the Touch Interface (RS-232 or USB), please follow instructions below.

- 1. Uninstall the touch driver.
- 2. Re-start the computer.
- 3. Remove the original Touch Interface (RS-232 or USB).
- 4. Connect the computer to the Touch Interface (RS-232 or USB) that you would like to use.
- 5. Install the Touch driver, then follow the step-by-step instructions as show on monitor.

PLEASE NOTE!

Don't plug in both the RS-232 and USB cables! Doing so may cause a driver conflict, making your touch screen inoperable.

PT1545P Install Instructions:

If you are using a PC running, Windows® 7/8, VISTA, XP, 2000, follow the instructions below:

- 1. Power on the PC.
- 2. Make sure that the USB cable is connected to the computer.
- 3. Visit www.planar.com/support.
- 4. Follow the step-by-step instructions as shown on the pop-up windows.

If you are using a PC running driver Linux kernel 2.6.x (32 bit & 64 bit), follow the instructions below:

- 1. Power on the PC.
- 2. Make sure that the USB cable is connected to the computer.
- 3. Visit www.planar.com/support.
- 4. Follow the step-by-step instructions as shown on the pop-up windows.

If you are using a PC running Windows® XP Embedded, follow the instructions below:

Express:

- 1. Power on the computer.
- 2. Make sure that the USB cable is connected to the computer.
- 3. Be sure that your EWF is disabled. If your EWF is enabled, please disable the EWF by using the EWF Manager command.
- 4. Once the EWF is disabled click on the XP driver at www.planar.com/support. and follow the step-by-step instructions as shown on the pop-up windows.

Custom:

- 1. Power on the computer.
- 2. Make sure that the USB cable is connected to the computer.
- 3. Follow the step-by-step instructions found in the zipped file at www.planar.com/support.

If you are using a PC running Windows® CE, follow the instructions below:

- 1. Power on the computer.
- 2. Make sure that the USB cable is connected to the computer.
- 3. Using Platform Builder, build an image file by following the step-by-step instructions found in the zipped file at www.planar.com/support.

If you are using a PC running Linux or Apple® Mac OS, follow the instructions below:

- 1. Power on the computer.
- 2. Make sure that the USB cable is connected to the computer.
- 3. Follow the step-by-step instructions found in the zipped file at www.planar.com/support.

Technical Support

Cables and Accessories

To find cables and accessories for your Planar monitor, touch screen or other Planar products visit our online store at www.**PlanarOnline.com**.

Technical Support

Visit Planar at http://www.planar.com/support for operations manuals, touch screen drivers, warranty information and access to Planar's Technical Library for online troubleshooting. To speak with Planar Customer Support please have you model and serial number available and dial:

Planar Support

Tel: 1-866-PLANAR1 (866-752-6271) or +1 503-748-5799 outside the US.

Hours: 24 hours a day, 7 days a week.

Toll or long distance charges may apply.

Planar Systems, Inc.

Customer Service

24x7 Online Technical Support: http://www.planar.com/support

1195 NW Compton Drive

Beaverton, OR 97006-1992

Tel: 1-866-PLANAR1 (866-752-6271) or +1 503-748-5799 outside the United States.

Hours: 24 hours a day, 7 days a week

© 2013 Planar Systems, Inc. 10/13 Planar is a registered trademark of Planar Systems, Inc.

Other brands and names are the property of their respective owners.

Technical information in this document is subject to change without notice.

020-1020-00E 820450065105